



## LED INSTANFIT LAMPS VARIOUS SIZES AND COLORS

Heading



## FASTEST...SIMPLE WAY TO SWITCH TO LED LAMPS USING YOUR PRESENT T8 INSTANT-START BALLAST

**HERE IS ALL YOU HAVE TO DO TO SWITCH TO THESE  
16.5 watt—2100 LUMEN LAMPS THAT ARE RATED 40,000 HRS.**

- 1. Switch-off power to the fixture**
- 2. Remove diffuser (if provided)**
- 3. Remove the existing fluorescent lamp from the fixture**
- 4. Install the LED T8 InstantFit lamp for each lamp removed**
- 5. Replace diffuser**
- 6. Switch on power to the fixture....that's it....**

**NO DRIVER BOARDS.... IT IS THAT SIMPLE!**

**Operates temperature of -4F (-20c)  
\*Note product NOT dimmable**

**Available in following colors:  
3000k, 3500k, 4000k & 5000k**

**E. B. LIGHTING & SUPPLIES, INC.**

1107 East Baltimore St., Baltimore MD 21202

410-276-7617

fax: 410-276-7307